


Domestic Hot Water Flat Plate



NOTE
Outdoor furnace water temperature setpoint should be set at 185°F minimum.

For illustration purposes only, water heater styles may vary.

*If domestic water has high concentrations of minerals, it is recommended to install a water softener and install plate exchanger with push-fit fittings or brass unions for easier removal.

NOTE
Installer must comply with all applicable codes and regulations.

