




Wiring Diagram Using a Zone Valve Wired Directly into the Control Box of the Furnace



For illustration purposes only:
 • Existing thermostat style may vary.
 • Location of thermostat may vary.

NOTE
 Thermostats must be installed by qualified technician.

